

For NOMAD...

1) Please remove the red cap on the backside of NOMAD first



2) Attach the phone mount adapter to the backside of NOMAD by the red cap



3) Slide the phone mount into the phone mount holder part and tighten it by the nylon screw



4) Attach your phone to the Phone mount holder, align the edges of phone to the edges of NOMAD



5) Use apps like Stellarium or Photopills to find the alignment target Polaris/ NCP Northern Hemisphere or SCP for the Southern Hemisphere.



6) Follow the arrow guide of the app then adjust the setup for polar alignment

For MSM tracker:

Please use the 3/8 screw coming with the tracker to attach the phone mount to the bubble level side.