THE SUPERIOR LENS CLEANING SYSTEM FOR ALL ULTRA COMPACT OPTICAL SURFACES

Ultra Compact Digital Cameras • Camcorders • Telescopes

LensPen MicroPro's cleaning tip is impregnated with a revolutionary non-liquid cleaning compound that absorbs oily residues and contaminants safer, easier and more effectively than any other method.






replenishes the cleaning compound and keeps the tip protected when not in use.

A pocket clip lets you attach it to anything and it's compact enough to throw in a pocket or a camera bag.

A high quality, all natural retractable brush lets you safely remove dust or hard particles from the lens surface.

Instructions for Use



Remove expose Wipe a smudg

Remove cap to expose cleaning tip. Wipe away any smudges with a smooth, circular motion. 3

Replace cap and turn half way to replenish the non-liquid cleaning compound.

NOTE: In cases of hardened deposits, breathe lightly on the lens, then wipe off completely with LensPen MicroPro.

The quality lens cleaning instrument is manufactured in a "clean room" environment to assure that the cleaning tip of LensPen MicroPro is free of any unwanted hard particles when purchased. For maximum performance and safety to the lens, use LensPen MicroPro according to instructions provided

