

## Procedure for removing eyepiece rubber grip

1. Hold the eyepiece by the nosepiece section and turn the rubber grip clockwise to loosen as shown in the photo.



2. Hold the eyepiece by its body and remove the rubber grip by pulling it past the end of the nosepiece.



3. Slip the provided ring over the nosepiece and tighten as shown.



4.

