

Instructions for Potentiometer Replacement

Remove the four screws attaching the mirror assembly and set the mirror assembly aside.

Remove the control knob by gently prying loose with a small screwdriver.

Use a 10 mm wrench to remove the shaft nut from the potentiometer. Push the potentiometer through the inside of the instrument and out through the battery compartment.

Note where the existing wires attach to the potentiometer and cut the wires next to the solder lugs.

Strip $\frac{1}{4}$ " of insulation from the wires and solder into place on the new potentiometer.

Reassemble in reverse order noting the location tab on the potentiometer. Make sure the switch is off before installing the new control knob. Take care to not over tighten the screws.