

How to Use the Illuminator:

1. Install the batteries:

- Unscrew the illuminator body.



- Insert two LR754 cell batteries into the battery compartment.



- Screw the illuminator body back together to secure the batteries.



2. **Attach to the polar scope:** Screw the illuminator into the threaded hole on Polar Scope A.



3. **Turn on the illuminator:** Rotate the top knob to the right to activate the red light.



4. **Align and Fine-Tune:** You are ready to do the polar alignment now. During alignment, you can adjust the red light brightness by turning the knob left or right as needed.

