

Q-FOCUSER-LP2RP INSTALLATION INSTRUCTIONS

Installation of the Q-Focuser-LP2RP is straightforward and requires only a few simple steps.

Tools needed: small diameter Philips head screwdriver, 2mm hex key (not provided).

1. Remove the fine and coarse focus knobs from the Long Perng focuser.



- 2a. **Standard Version** - Slide the provided 3D printed coupler onto the brass focuser pinion shaft until it stops. Secure with two set screws, using the 2mm hex key. Do not over tighten the screws. See image below.
 - 2b. **High Precision Version** – Using the 2mm coupler provided with the Q-Focuser, slide the coupler onto the focuser fine focus pinion shaft as far as it will go. Clamp the coupler onto the focuser fine focus pinion shaft using the 2mm hex key. (Not pictured)



3. Slide the bracket onto the silver body of the focuser until the focuser hits the stop on the inside of the bracket. Rotate the bracket to the desired position and tighten the two Philips head screws to clamp the bracket onto the focuser.



- 4a. **Standard Version** - Slide the Q-Focuser pinion into the coupler. Note that there is a flat on the coupler hole that matches the flat on the Q-Focuser pinion. Once the Q-Focuser pinion is inside the coupler, rotate the Q-Focuser until the set screws in the coupler are visible through the side access holes in the bracket. Secure the coupler to the Q-Focuser pinion with set screws. Do not

over tighten the screws. Attach the Q-Focuser to the bracket using the supplied M3x20mm socket head screws.

- 4b. **High Precision Version** – Slide the Q-Focuser pinion into the coupler. Secure the Q-Focuser to the bracket using the supplied M3x20mm socket head screws. Using the 2mm hex key, tighten the coupler onto the Q-Focuser pinion through the access hole closest to the Q-Focuser.



Please inform of any additions or corrections to these directions by sending an email to buckeyestargazer@gmail.com